Calphalon®

No Peek™ Round Waffle Maker
QUICK START GUIDE

Model HE500RW

BEFORE FIRST USE

- Place on level surface near a suitable 2-prong polarized outlet.
- Remove packing materials.
- Wipe waffle plates with a watered down mild detergent or soap.
- Turn waffle maker on by plugging power cord into outlet.

BEGIN COOKING

- Turn knob to choose the shade of browning.

  Light – waffles are cooked throughout, but exterior browning is minimal

  Medium – waffles are golden brown

  Dark – waffles are a deep golden brown and the exterior is crispy
- Preheat waffle maker.
- Once preheated, the No Peek™ **Ready light** illuminates.
- Open the waffle maker and pour waffle batter (approximately ½ cup) evenly over the bottom plate. Close the waffle maker.
- The No Peek™ Ready light will re-illuminate when the waffles are ready. Open the waffle maker and remove the waffles with a nonstick safe utensil.

TURNING OFF

To turn off the waffle maker, grasp the plug securely and remove it from the outlet. Allow waffle maker to cool completely before cleaning.

TIPS FOR SUCCESSFUL OPERATION

- Use approximately 1/2 cup of batter for making a waffle.
- Preheating the waffle maker completely (as indicated by the illuminated No Peek™ Ready light) helps prevent waffles from sticking to the plates.
- The level of browning will vary depending on the type of batter used. Batters with higher sugar content will result in darker waffles, while lower sugar content batter will result in lighter waffles.
- **Nonstick cooking sprays are not recommended for this waffle maker.** Spraying the waffle plates with nonstick cooking spray may build up a residue on the hot plates.

Calphalon®
A Newell Rubbermaid Company
calphalon.com

©2011

BLACK

QUICKSTART GUIDE TRI-FOLD (US)

VERSION: ____________	DATE: ____________
PROJECT INITIATOR: ____________	DATE: ____________
DESIGNER: ____________	DATE: ____________
COPY APPROVER: ____________	DATE: ____________